


Chipatronic have a large range of accessories to connect cameras, monitors, DVRs etc. and convert between cable types or terminations.

4 Pin Cables and Connections

Many cameras and monitors use 4 Pin "aviation style" connectors which allow a single cable to carry both power and video signals and allow a quick and positive method of connection or disconnection. Standard arrangement is for the monitor to have *Male* and cameras to have *Female* terminations.

Caravan cables use the same standard so there are *car side* and *van side* versions although this can be changed by using a gender changer adaptor of either *Male-to-Male* or *Female-to-Female* variety.

RCA adaptors are available for both the *Male* and *Female* 4 Pin to connect to RCA sockets and also DC power.



CBB Curly Cable suits the **CC** series caravan cables to connect car and caravan. When not in use this leaves a weatherproof plug on both car and caravan with heavy duty cable, rustproof alloy shell and keyed plugs.

CH-MB Mounting Brackets suits the **CC** series caravan cables and are locally made from quality 1.6mm Stainless Steel.

Standard Accessories

CH-4MRCA	4 Pin Male - RCA Adaptor with DC In Yellow = Video White = Audio/2 nd Video DC Power In (Male). Use with RCA input monitor and 4 pin camera/caravan camera	
CH-4FRCAM	4 Pin Female - RCA Adaptor with DC Out Yellow = Video White = Audio/2 nd Video DC Power Out (Female). Use with RCA Camera into 4 pin cable.	
CH-4PM2M	4 Pin Male - Male Adaptor Gender changer - 4 pin Female to Male	
CH-4PF2F	4 Pin Female - Female Adaptor Gender changer - 4 Pin Male to Female	
ARF2F	Female to Female RCA Gender Changer - RCA Male to Female	
ARM2M	Male to Male RCA Gender changer - RCA Female to Male	
CH-4F2M	4 Pin Input adaptor, 2 cameras through 1 cable: 2 x 4 Pin Male to 1 x 4 Pin Female Use with dual cameras using one cable	
CH-4M2FX	4 Pin Monitor Output adaptor, monitor end cable: 1 x 4 Pin Male to 2 x 4 Pin Female Suit dual cameras using one cable	
CH-DCMPC	DC Power plug (Female) Use with CH-4MRCA for power to camera through cable	
CH-RCASPLIT	RCA Splitter 2 x RCA Female In: 1 RCA Male Out.	
CH-DCM2M	DC Male to Male	
CH-4PPS	4 Pin Plug & Socket Set to re-wire cable Solder connections. Cable Clamp	
CH-5PFPLUG	Caravan plug with short tail - Female connector. Convert basic 4 pin cable to caravan plug - curly cable system. Car side	
CH-5PPLUG	Caravan plug with short tail - Male connector. Convert basic 4 pin cable to caravan plug - curly cable system. Caravan side	
CH-4FRCAS	4 Pin Female to RCA Female connector. For RCA camera connection into 4 pin monitor. Single RCA, no power to camera.	
CH-5PPS	5 Pin Plug & Socket Set to re-wire caravan cable connections or make trailer plug set Solder connections	